RAVEN ERROR MESSAGES

K0

K0 indicates an undefined and unrecoverable printing error. Check the LED Display on the Raven for status code report; follow instructions to fix problem, then type <CR>. no status code report shows and On-Line LED is lit, Press doesn't like your file. Type Swat or boot; when the executive comes back, type Press rep <CR> to try a reprint. If t fails, type @Server.cm and go fix your file.

K1

K1 indicates that the printer is out of paper. The LED status code display on the prin will say C4. Follow the directions on the printer to refill, being sure to refill both and to replace each cassette in the slot whence it came. The curl goes up. If the stat codes still complain, wiggle the cassettes and the locking handle until it's happy. Whe status codes are contented, type <CR> and the file will print.

K2

K2 indicates that the printer has shut itself down from lack of use {a feature of Raven printers}. The print request will restart the Raven; until it is ready the LED status c display on the printer will say L1. While it warms up, Press continues to poll the prin to see if it is ready; you can see the K2 change to P1 and back again. When the Raven ready, the next time Press polls it will respond affirmatively, and it will print. You longer have to do anything except be patient.