

ProcL Multiwire Rework Instructions for Rev Cg to Rev Ch

1. Cut Chip Leg k15-10 (RBaseBypass')
2. Install MC102 @ location i10
3. Install the following blue wires  
k15-11 to i10-7 (NextMacroDly')  
g19-9 to i10-6 (Hold)  
i10-6 to g19-2 (RBaseBypass')  
i10-1 to i10-16 (GND398)  
i19-4 to e21-12 (Curr=Next')
4. Remark board using indelible ink to Rev Ch

ProcL-MWrev-Cg-to-Ch-rework.sil

XEROX	Project	Reference	File	Designer	Rev	Date	Page
PARC	Dorado	MW-rev-Cg to Ch Rework	See Above	Diebert	Ch	3/17/80	01