

16. CONTENTS OF THE ALTO DISK

The following files are ordinarily kept on the Maxc2 Alto's disk, in addition to standard Alto subsystems.

Maxc-related files

MICRO.RUN	Microcode assembler
MIDAS.RUN	Microcode loader/debugger
MIDAS.*	Various auxiliary files needed by Midas
SYS2.MB	PDP-10 emulator microcode
TENLOAD.MIDAS	Midas commands to load microcode
INIT.MIDAS	Midas commands to load and dump newly-assembled microcode
MEXECGO.MIDAS	Midas commands to load microcode, start Micro-Exec
TENGO.MIDAS	Midas commands to load microcode, start Tenex
ALTIO.RUN	Nova I/O control program
TM.RUN	Maxc memory diagnostic (runs on Alto)
MEMBASH.RUN	Maxc memory contention exercisor
SMIDIAG.RUN	Alto System Maintenance Interface diagnostic

Microprocessor diagnostics and command files

DGBASIC.MB	DGBASIC.MIDAS
DGP.MB	DGP.MIDAS
DGALU.MB	DGALU.MIDAS
DGIMH.MB	DGIMH.MIDAS
DGIML.MB	DGIML.MIDAS
DGRL.MB	DGRL.MIDAS
DGI.MB	DGI.MIDAS
DGM.MB	DGM.MIDAS
DGMR.MB	DGMR.MIDAS
DGREG.MB	DGREG.MIDAS
DBEG.MB	

The current microprocessor diagnostic sources are ordinarily kept on the Maxc2 Alto disk as well.