Command Summary:

? Displays current values for parameters Black, White, XStart, XLen, YStart, YLen

- ! Turns the controller on or off (toggle)
- b Sets black threshold-- prompts for a value between 0 and 255
- c Calibrates the Jasmine-- expects to see a white sheet of paper
- d Sets Delay parameter
- e Erase the screen
- f Advance paper-- prompts for number of steps
- h Halftone sample input
- i Initialise RAM
- 1 Sets length of scan
- n Ejects old page and accepts new page input
- o Output to file-- expects filename of form <name>.ais
- q Quit Scan.bcd
- r Reverse paper-- prompts for number of steps
- s Set skip count
- t Set time for integration-- initially 656 (38 uSec ticks)
- w Set white threshold-- prompts for a value between 0 and 255
- x Followed by "l" or "s", sets XLen or XStart parameters
- y Followed by "l" or "s", sets YLen or YStart parameters
- z Zoom halftone mode-- draw rectangle with mouse red, yellow to move origin, and blue to invoke